

# Z1-12 Lighting Instructions

## STEP 1 TURN ON GAS SUPPLY AT PROPANE CYLINDER



STEP 2 POSITION FLAME AS SHOWN



STEP 3 PUSH IN CONTROL KNOB AND TURN COUNTER-CLOCKWISETO IGNITE GAS

#### KEEP THE CONTROL KNOB PUSHED IN FOR AT LEAST 15 SECONDS

This will allow the thermocouple safety device to heat up. If the thermocouple is not heated correctly the gas supply will automatically be cut off.

### IF THE FLAME GOES OUT FOR ANY REASON

Turn off the gas supply at the cylinder and wait two mintes before repeating steps 1 through 3 above.

#### TO ADJUST HEAT

Push in control knob and turn counter-clockwise to increase heat or clockwise to decrease heat.

#### TO TURN HEATER OFF

Push in control knob and turn clockwise to stop. Flame will extinguish. Turn off the gas supply at the cylinder.